



Outdoor Heater Instructions

lighting instructions:

1. Turn the control knob to "OFF" position.
2. Turn LP cylinder gas valve to fully open position.
3. Push in the gas control knob and turn counter-clockwise to "LOW" position, this will light the burner. If needed keep pressing and turning control knob counter-clockwise until the burner lights. (You will hear 1 clicking noise).
4. Once the burner is lit, continue to keep the control knob pressed in for at least 30 seconds. then release control knob.

Re-Light:

1. Turn the knob to "OFF" position.
2. Wait (5) minutes before attempting to relight pilot.
3. Repeat steps beginning with step 2 of the lighting instructions above.

When finished using:

- Turn gas tank off.
- Turn the control knob to off position.
- Turn LP cylinder to off position.
- Do not touch or move heater within at least 45 minutes of use.

Operation

- The burner may be noisy when initially turned on. To eliminate excessive noise from the burner, turn the control knob to "LOW" position. Then, turn the knob to the level of heat desired.

When heater is ON:

- Emitter screen will become bright red due to intense heat. The color is more visible at night. Burner will display blue flame. These flames should not be yellow or produce thick black smoke, indicating an obstruction of airflow through the burners.
**Operation pressure check: If the flame is very small, this is because the supply pressure is not enough.

Description:

Our Commercial Patio Heater is the most powerful and fashionable heater on the market.

Specifications:

1. 46,000 BTU's
2. Stainless steel tank housing top and heater base
3. Powder-coated mocha finish
4. Reliable piezo igniter
5. Comes with Propane Gas for 6-8 hours of use
6. Uses standard 20 LB.
7. Safety auto shut-off tilt valve
8. Wide base for stability
9. Heats out to up to 5 ft.
10. Consumer Alert: Can't be under tents